

## Bedienungsanleitung Buchscanner **Bookeye**® 5

### Kontaktarme Nutzung direkt am Gerät (USB-Stick erforderlich)

1. Der Buchscanner darf täglich pro Person maximal eine halbe Stunde genutzt werden.
2. Vor der Benutzung müssen die Hände desinfiziert werden.
3. Zum Starten *Urheberrechts- und Datenschutzdisclaimer* auf Monitor **annehmen**.
4. Die *Sprache* über den Monitor (oben rechts) auswählen.
5. Buch auflegen. Buchwippe durch Verschieben der Seitenteile auf die passende Größe einstellen (Buchdicke max. 12 cm).
6. Scan mit Fußschalter auslösen.
7. Vorgang wiederholen bis der Auftrag fertig ist.
8. USB-Stick anschließen (am Gerät vorne rechts).
9. Auf Monitor (oben rechts) **Übertragen** auswählen.
10. Auf Stick speichern.
11. Fertig!

## User manual book scanner **Bookeye**® 5

### Low contact use (USB stick required)

1. The book scanner may be used for a maximum of half an hour per person per day.
2. Hands must be disinfected before use.
3. Accept *Urheberrechts- und Datenschutzdisclaimer* on monitor to start.
4. Choose *Language/Sprache* (top right on monitor).
5. Place the book on the table. Adjust the book cradle to the appropriate size by moving the side parts (book thickness max. 12 cm).
6. Activate scan with foot switch.
7. Repeat the procedure until the job is finished.
8. Connect USB stick (front right of the device).
9. Select Transfer (top right on monitor).
10. Save to stick.
11. Finished!